

Accessories Included

Digital Camera

Camera Driver & Ulead Software & User Manual 2 x AA Batteries







Camera Pouch

Wrist Strap

Quick Start Guide










USB Cable





Introduction

Top

Front

External View

View Finder

Lens Focus Switch

11

→ Flash

→ Self-timer LED

→ USB Connector

→ DC In Connector

Shutter Button

▼ Mode Dial

Konica

KD-25